

Настройка PLANET ATA

Настройка PLANET VoIP Phone Adapter ATA (Аналоговый телефонный адаптер)

Если ATA настраивается в первый раз, то по умолчанию установлен IP **192.168.0.1**.

Если уже настраивался и вы забыли какой IP установлен на ATA, для того чтобы попасть на web интерфейс настроек.

Нужно сбросить настройки ATA по умолчанию нажать на кнопку **RESET**, которая находится возле разъема питания.



После сброса настроек заходим на web интерфейс набрав в браузере **192.168.0.1**.

Вам будет предложено ввести логин и пароль, по умолчанию логин **root**, пароль отсутствует.

http://192.168.0.1/

Enter Network Password

Please type your user name and password

VoIP Phone Adapter Configuration

User Name

Password

Save this password in your password list

Заходим в конфигурацию PLANET **Network >> Network Settings** и выставляем IP например так:

- **IP Type: Fixed IP** (тип IP адреса)
- **IP : 192.168.1.10** (IP адрес ATA через который Вы будите заходить на web интерфейс)

- **Mask: 255.255.255.0** (маска подсети)
- **Gateway: 192.168.1.1** (шлюз)
- **DNS Server 1: 62.122.137.7** (IP DNS сервера провайдера)
- **DNS Server 2: 62.122.137.4** (IP DNS сервера провайдера)

Жмем **Submit** (подтверждаем наши действия)

The screenshot shows the PLANET VoIP Phone Adapter Configuration Menu. The left sidebar contains the following menu items: Phone Book, Phone Setting, Network (highlighted with a red box and a red arrow pointing to the Network Settings sub-menu), SIP, DDNS Settings, NA, Advanced Settings, System Auth., Save & Reboot, System Settings, and Reboot without Saving. The main content area is titled "Network Settings" and contains the text "You could configure the Network settings in this page." Below this, there are two configuration sections: "WAN Setting" and "PPPoE Setting". The WAN Setting section is highlighted with a red box and contains the following fields: IP Type (Fixed IP selected), IP (192.168.1.10), Mask (255.255.255.0), Gateway (192.168.1.1), DNS Server1 (62.122.137.7), DNS Server2 (62.122.137.4), and MAC (00304f56494c). The PPPoE Setting section contains fields for User Name and Password. At the bottom of the page, there are two buttons: Submit (highlighted with a red box) and Reset.

PLANET
Networking & Communication

**VoIP Phone Adapter
Configuration Menu**

Phone Book

Phone Setting

Network

Status

SIP **Network Settings**

DDNS Settings

NA

Advanced Settings

System Auth.

Save & Reboot

System Settings

Reboot without Saving

Network Settings

You could configure the Network settings in this page.

WAN Setting


IP Type:	<input checked="" type="radio"/> Fixed IP	<input type="radio"/> DHCP Client	<input type="radio"/> PPPoE
IP:	192.168.1.10		
Mask:	255.255.255.0		
Gateway:	192.168.1.1		
DNS Server1:	62.122.137.7		
DNS Server2:	62.122.137.4		
MAC:	00304f56494c		

PPPoE Setting

User Name:	<input type="text"/>
Password:	<input type="text"/>

Submit **Reset**

Сохраняем настройки и перезагружаем конфигурацию **Save & Reboot >> Save**.



Заходим на наш АТА набрав в браузере IP 192.168.1.10.

Далее нужно [зарегистрировать NGN номер](#) и получить на указанную почту при регистрации настройки, **SIP логин** и **SIP пароль**.

Настраиваем соединение с **sip.tj** идем **SIP Settings >> Service Domain** и настраиваем как показано на рисунке подставляя свои данные которые получили при регистрации нового NGN номера:

- **Active: On**
- **Display Name: (Ваше имя или номер телефона)**
- **Line Number: SIP логин** (который получили при регистрации NGN номера.)
- **Register Name: SIP логин** (который получили при регистрации NGN номера.)
- **Register Password: SIP пароль** (который получили при регистрации NGN номера.)
- **Domain Server: sip.tj**
- **Proxy Server: sip.tj**
- **Outbound Proxy: sip.tj**

Жмем **Submit** (подтверждаем наши действия)



Service Domain Settings

You could set information of service domains in this page.

Realm 1 (Default)	
Active:	<input checked="" type="radio"/> On <input type="radio"/> Off
Display Name:	3777025
Line Number:	sip3777025
Register Name:	sip3777025
Register Password:	••••••••
Domain Server:	sip.tj
Proxy Server:	sip.tj
Outbound Proxy:	sip.tj
Status:	Not Registered

Сохраняем настройки и перезагружаем конфигурацию **Save& Reboot >> Save**.



Save & Reboot

You have to save changes to effect them.

Save Changes:

После выше проделанных действий в окне **SIP Settings >> Service Domain** увидите снизу

Status: Registered (регистрация прошла успешно)

The image shows two parts of the PLANET VoIP Phone Adapter configuration interface. On the left is the 'VoIP Phone Adapter Configuration Menu' with a sidebar containing various settings categories. 'SIP Settings' is highlighted in red, and a red arrow points to the 'Service Domain' sub-menu. On the right is the 'Service Domain Settings' page for 'Realm 1 (Default)'. It contains a table of configuration parameters. The 'Status' field at the bottom is highlighted with a red box and shows 'Registered'.

Realm 1 (Default)	
Active:	<input checked="" type="radio"/> On <input type="radio"/> Off
Display Name:	3777025
Line Number:	sip3777025
Register Name:	sip3777025
Register Password:	••••••••
Domain Server:	sip.tj
Proxy Server:	sip.tj
Outbound Proxy:	sip.tj
Status:	Registered

На этом настройка АТА PLANET окончена.